

# Part List, Mechanical

Applicable for W960









## CONTENTS

<b>1</b>	<b>General .....</b>	<b>2</b>
<b>2</b>	<b>Parts Common to W960 .....</b>	<b>3</b>
<b>3</b>	<b>Revision History .....</b>	<b>14</b>









# 1 General

This Part List includes all parts possible to replace by using the Mechanical Repair Process.  
Parts available to order will be found in the Web Shop.









## 2 Parts Common to W960

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Battery Lid Asm	Battery Lid Asm	SXK1040272/1	
		Stylus	Stylus	SXK1040321	
		Screw 1.4x4	Screw 1.4x4	SXA1095031	
		Antenna Lid Asm	Antenna Lid Asm	SXK1040273/1	









## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Screw black Torx	Screw black Torx	SXA1098029	
		Front Cover	Front Cover	SXK1040309/Z	
		LCD, W/O Touch Panel	LCD, W/O Touch Panel	RNH80114	
		Frame Sub Asm	Frame Sub Asm	SXK1040278/1	









## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Mesh Loud Speaker	Mesh Loud Speaker	SXA1097443	
		Camera gasket	Camera gasket	SXA1097446	
		Earspeaker Bujeon w/o gasket	Earspeaker Bujeon w/o gasket	RLE90824/22	
		Spring Bracket	Spring Bracket	SXA1098106	









## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Shielding Lid, CIF camera	Shielding Lid, CIF camera	SXA1097222	
		Keypad	Keypad Latin Keypad Chinese Keypad Arabic Keypad Cyrillic Keypad Taiwan Keypad Hebrew	SXA1097441/1 SXA1097441/2 SXA1097441/3 SXA1097441/4 SXA1097441/5 SXA1097441/7	
		Flex Asm Keyboard	Flex Asm Keyboard	SXK1040282	
		BtB Flex	BtB Flex	ROA2195837	

## Parts *continued*









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		BtB flex poron	BtB flex poron	SXA1097986	
		Acoustic Box	Acoustic Box	SXK1040253	
		Flash Flex Asm	Flash Flex Asm	SXK1040247	
		Shielding Box, MPixel Camera	Shielding Box, MPixel Camera	SXA1097062	

## Parts *continued*









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Camera, 3MPixel	Camera, 3MPixel	KNC20140	
		Microphone Grommet	Microphone Grommet	SXA1097319	
		KRH LABEL, MATERIAL	KRH LABEL, MATERIAL	SVF9301450	
		Light Guide Assembly	Light Guide Assembly	SXK1040314	











## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		System Connector	System Connector	RNV79936	
		Dust gask.large sys.conn	Dust gask.large sys.conn	SXA1096165	
		Camera Module, QCIF	Camera Module, QCIF	KNC20141	
		Gasket LCD upper	Gasket LCD upper	SXA1097921	









## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Liquid Intrusion Indicator	Liquid Intrusion Indicator	SXA1094884	
		Screw M1,6 x 3,0	Screw M1,6 x 3,0	SXA1097221	
		Sub PWB ASM	Sub PWB ASM	ROA2195784	
		Battery Spring	Battery Spring	SXA1098124	


## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		MOTOR UNIT VIBRATOR	MOTOR UNIT VIBRATOR	BKE902019/27	
		Gasket Microphone	Gasket Microphone	SXA1097928	
		Net Microphone	Net Microphone	SXA1097250	
		Camera Key	Camera Key	SXA1097768	

## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Key, Volume	Key, Volume	SXA1097380/1	
		On/Off Key	On/Off Key	SXA1097923	
		Separator	Separator	SXA1097932	
		Antenna Flex	Antenna Flex	KRE1011538	

## Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Illumination Flex	Illumination Flex	ROA2195846	

### 3 Revision History

Rev.	Date	Changes / Comments
1	2007-11-29	Initial release
2	2008-02-19	Added ROA2195846