



Sony Ericsson

Part List

- mechanical -



Xperia Mini Pro

SK17i, SK17a

CONTENTS













1	Part List	3
2	Revision History	10

















1 Part List

















The following parts are available for order in 'E-star'.

















The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.











Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

















Designation	Part No.	Part	Location
Audio Jack Adhesive Foil	1242-9472		
<u>Battery Cover</u> Battery Cover Assy Black Battery Cover Assy Pink Battery Cover Assy Turquoise Battery Cover Assy White	1242-2400 1246-5147 1246-5149 1246-0292		
<u>Battery Cover Assy Cobrand</u> Battery Cover Assy Cobrand Black Battery Cover Assy Cobrand White	1247-3025 1247-3029		
<u>Main Camera</u> Camera 5.1 MPixel CMOS	1230-6587		
<u>Camera Key</u> Camera Key Black Camera Key White	1242-2021 1246-0483		
Camera Key FPC	1242-1879		









Designation	Part No.	Part	Location
<u>Camera Ring</u> Camera Ring Silver	1250-3752		
Camera Window	1250-3743		
<u>Co-Brand Label</u> Co-Brand Label Movistar Black Co-Brand Label Movistar White Co-Brand Label Orange Black Co-Brand Label Orange White	1247-8301 1247-8302 1247-8293 1247-8294		
Conductive Copper Foil	1248-3571		
Conductive Cushion	1242-2377		
<u>Audio Jack Connector</u> Conn 0p	1230-9135		
Core Unit Label	1243-7509		
<u>Receiver</u> Ear Speaker 15.0 Rectangular	1231-4565		

Designation	Part No.	Part	Location
ET922 Screen Protector	1250-0052		
First Mic Mesh	1242-2364		
Flash LED FPC	1242-1878		
Flash LED FPC Adhesive Foil	1243-6006		
GPS Shielding Conductive Gasket	1243-0427		
Hinge Assy Adhesive Foil	1243-8928		
Hinge FPC	1241-7544		
Hinge FPC Clip	1242-9223		

Designation	Part No.	Part	Location
<u>Hinge Assy</u> Hinge Slide Top Assy Black Hinge Slide Top Assy White	1242-2025 1246-0356		
<u>Water Indicator</u> Water Indicator 3x3	1223-5172		
Loud Speaker Gasket	1242-2349		
<u>Loud Speaker Mesh</u> Loud Speaker Mesh Black	1242-2363		
<u>Loudspeaker</u> Loudspeaker 11x15	1001-0324		
<u>Lower Front Cover Assy</u> Lower Front Cover Assy Black Lower Front Cover Assy White	1242-2274 1246-0407		
<u>Lower Rear Cover Assy</u> Lower Rear Cover Assy Band 125 Lower Rear Cover Assy Band 18	1242-4091 1242-2305		
Main Antenna Switch Protective Film	1243-9968		

Designation	Part No.	Part	Location
Main Keypad Domesheet	1246-7502		
Micro SD 2Gb Micro SD 4Gb	1218-7894 1210-7834		
<u>Micro USB Cover</u> Micro USB Cover Black Micro USB Cover White	1242-2319 1246-0484		
<u>Main Keypad</u> Main Keypad AZERTY Black Main Keypad AZERTY White Main Keypad QWERTY Arabic Black Main Keypad QWERTY Arabic White Main Keypad QWERTY Bopomofo Black Main Keypad QWERTY Bopomofo White Main Keypad QWERTY BRPT Black Main Keypad QWERTY BRPT White Main Keypad QWERTY Chinese Black Main Keypad QWERTY Chinese White Main Keypad QWERTY Cyrillic Black Main Keypad QWERTY Cyrillic White Main Keypad QWERTY Greek Black Main Keypad QWERTY Greek White Main Keypad QWERTY Hebrew Black Main Keypad QWERTY Hebrew White Main Keypad QWERTY Latin Black Main Keypad QWERTY Latin White Main Keypad QWERTY NODK Black Main Keypad QWERTY NODK White Main Keypad QWERTY SEFI Black Main Keypad QWERTY SEFI White Main Keypad QWERTY Thai Black Main Keypad QWERTY Thai White Main Keypad QWERTZ Black Main Keypad QWERTZ White	1247-8280 1247-8289 1247-8273 1247-8281 1247-8275 1247-8283 1247-8368 1247-8387 1247-8362 1247-8388 1247-8278 1247-8286 1247-8279 1247-8288 1247-8274 1247-8282 1242-2022 1246-0289 1247-8379 1247-8391 1247-8378 1247-8389 1247-8276 1247-8284 1247-8277 1247-8285		
<u>Power Key</u> Power Key Black Power Key White	1242-2023 1246-0481		

Designation	Part No.	Part	Location
<u>Receiver Deco</u> Receiver Deco Black Receiver Deco White	1242-2475 1246-0348		
<u>Receiver Mesh</u> Receiver Mesh Black Receiver Mesh White	1242-2308 1246-0331		
<u>Screw Cap</u> Screw Cap Black Screw Cap White	1242-2492 1246-0870		
Screw M1.4X2.0	1230-6681		
Screw Other Len:1.6 Diam:1.4	1251-4334		
			
Screw Torx Len:3.1 Diam:1.4	1242-2326		
<u>Second Mic Mesh</u> Second Mic Mesh Black	1242-2365		

Designation	Part No.	Part	Location
Shielding Can Lid ABB	1243-0605		
Shielding Can Lid DBB	1246-4522		
Shielding Can Lid RF	1246-4518		
<u>Touch/Display Front Cover Assy</u> Touch/Display Front Cover Assy Black Touch/Display Front Cover Assy White	1252-1670 1252-1672		
VGA Camera Rubber Carrier	1248-3847		
<u>Volume Key</u> Volume Key Black Volume Key White	1242-2007 1246-0482		
WLAN Shielding Adhesive Foil	1243-0431		



2 Revision History

Rev.	Date	Changes / Comments
1	2011-Jul-12	Initial release