

# Part List

- mechanical -



**ST26i, ST26a**

**CONTENTS**

1 Part List ..... 3















2 Revision History ..... 7

## 1 Part List

The following parts are available for order in 'E-star'.













The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

Designation	Part No.	Part	Location
Antenna BT WIFI	1237-5889		
Antenna GPS	1237-5890		
<u>Antenna Main</u> Antenna Main Band125 Antenna Main Band18	1228-0173 1237-5892		
<u>Battery Cover</u> Battery Cover Black Battery Cover Gold Battery Cover Pink Battery Cover White	1265-3124 1266-4452 1266-4450 1265-3121		
Coaxial Cable	1264-5384		
Connector Film	56GAFH00000		
Connector Film	56GAFH00000		

Designation	Part No.	Part	Location
Core Unit Label	1264-2170		
Front Cover Display Assembly	120AFH00001		
LCM connector sponge	56DAFH00006		
Link FPC	1264-1968		
Link FPC kapton	56GAFH00002		
<u>Loudspeaker</u> Loudspeaker 11x15	1001-0324		
<u>Main Camera</u> Camera 5 Mpixel	1261-5208		
Proximity rubber	450AFH0110A		

Designation	Part No.	Part	Location
Rear Cover	1265-3119		
Receiver	1244-5343		
Receiver Adhesive	56BAFH00000		
RF Rubber	455AFH0010A		
Rubber Flash Led White	450AFH0330A		
Screw Lanyard M1.6*3.2	F50001603200		
Screw M1.6*2.8	F50001602810		
Screw M1.6*4.2	F50001604210		

Designation	Part No.	Part	Location
Screw M1.6*4.2	F50001604210		
Side Key	1265-3122		
SIM SD Side Key FPC	1264-1977		
Speaker Adhesive	56DAFH00000		
Sub Board Assembly	120AFH00000		
Water Indicator	2500002900A		

## 2 Revision History

Rev.	Date	Changes / Comments
1	2012-Oct-9	Initial release
2	2012-Oct-11	Delete 1263-6090(Side slide type micro-SIM adapter) due to use 1257-9796 micro-SIM adapter as accessory.