

Part List Repair Specification, Mechanical

Applicable for W302









CONTENTS

1	General	2
2	Parts.....	3
3	Label Part List.....	12
4	Revision History	13



1 General

This Part List includes all parts possible to replace by using the Mechanical Repair Process.
Parts available to order will be found in the Web Shop.



2 Parts

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Battery Cover Assy	Batt Cover Assy white	1206-0343	
			Batt Cover Assy black	1205-5722	
			Batt Cover assy blue	1209-0758	
		Screw Cap	Screw Cap silver white	1206-0339	
			Screw Cap black	1205-5723	
			Screw Cap blue	1209-0760	Updated
		Screw	Screw	1205-5724	6 pcs
		Mic gasket	Mic gasket	S/254046885	

Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Co-brand Label	Co-brand Label Silver Generic Co-brand Label Black Generic Co-brand Label Vodafone Black/Black Co-brand Label Vodafone Silver/White Co-brand Label T-Mobile Black/Black Co-brand Label Orange/Black/Black Co-brand Label generic blue	S/253010443 1205-5721 1208-3354 1210-3516 1211-0200 1211-0202 1209-0753	Updated









Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments	
		Keypad	Keypad Silver Thai	S/254033086		
			Keypad Silver Stroke	S/254033099		
			Keypad Silver Hebrew	S/254033106		
			Keypad Silver Cyrillic	S/254033119		
			Keypad Silver Bopomofo	S/254033127		
			Keypad Silver Arabic	S/254033130		
			Keypad Silver Latin	S/253004255		
			Keypad Black Thai	S/254033151		
			Keypad Black Stroke	S/254033169		
			Keypad Black Hebrew	S/254033172		
			Keypad Black Cyrillic	S/254033180		
			Keypad Black Bopomofo	S/254033193		
			Keypad Black Arabic	S/254033205		
			Keypad Black Latin	1205-5718		
			Keypad Black Hindi	S/254035407		
			Keypad Bopomofo blue	1209-0764		
			Keypad Thai blue	1209-0767		
			Keypad stroke blue	1209-0768		
			Keypad Arabic blue	1209-0771		
			Keypad Cyrillic blue	1209-0772		
			Keypad Hebrew blue	1209-0775		
			Keypad Latin blue	1209-0752		









Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Sidekey Photo	Sidekey Photo silver	S/253015823	
		Front Assy	Front assy silver	1206-0342	
			Front assy black	1205-5717	
			Front assy blue	1209-0750.1	
		Side Key Volume	Sidekey Volume silver	S/253015836	
		Camera Rubber	Camera Rubber	S/254022723	









PaFrts *continued*









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Camera window Assy	Camera window Assy	S/254021784	
		Walkman key	Walkman key goldcrome (silver)	S/253015802	
			Walkman key platinchrome (black)	S/253016023	
		SIM M2 pba Assy	SIM M2 pba assy	1220-9600	
		Antenna Assy	Antenna assy	S/254054663	



Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		LCD Window Assy	LCD Window assy	1205-5720	S/254067243 Replaced by 1205-5720
		Speaker	Speaker	1208-3001	S/189827178 replaced by 1208-3001
		Receiver	Receiver	1208-3002	
		Vibrator	Vibrator	S/189757970	

Parts *continued*

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Camera Support Assy	Camera Support assy	S/254022984	
		Camera Flex Assy	Camera Flex assy	1206-2736	
		LCD Assy	LCD assy	1203-6349	
		LCD Metal Support	LCD Metal support	S/253002251	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Label	IMEI Label	1208-0743	
		LCD window sponge	LCD window sponge	S/253002355	
		Liquid intrusion label	Liquid intrusion indicator	1209-7282	
		Metal frame assy	Metal frame assy	1223-0254	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Rear cover assy	Rear cover assy white	S/254022976	
			Rear cover assy, black	S/254023006	
			Rear cover assy blue	1223-2700	

3 Label Part List

Pos.	Description	Part Number	Comments
	IMEI Label	1208-0743	

4 Revision History

Rev.	Date	Changes / Comments
1	2008-09-28	First Release
2	2008-10-02	New partnumber LCD Window assy S/254022236 New partnumber Camera window assy S/254021784
3	2008-11-25	Changed partnumber on LCD Window assy from S/254022236 to S/254067243
4	2009-03-18	New blue parts added
5	2009-06-10	New part number on the receiver
6	2009-07-22	Screw Cap blue added Co-brand Label generic blue updated
7	2010-02-23	Speaker part number S/189827178 replaced by 1208-3001
8	2010-02-23	LCD window assy part number S/254067243 Replaced by 1205-5720
9	2010-05-18	Changed partnumber on S/287257085 to 1223-0254.
10	2010-06-03	Changed part number from S/254039864 to 1220-9600
11	2011-01-04	Battery Cover White PN change from S/253011338 to 1206-0343