

Part List, Mechanical

Applicable for W380

Contents









1	General	2
1.1	View of W380	2
2	W380 Parts	3
3	Revision History.....	14




1 General











1.1 View of W380













2 W380 Parts









Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Upper Front Cover Assembly	Upper Front Cover Assy - Black	1206-9497	
			Upper Front Cover Assy - Dark Grey	1206-9465	
			Upper Front Cover Assy - Purple	1206-9498	
			Upper Front Cover Assy - Silver	1215-5957	
		Protective Plate Tape	Protective Plate Tape	1210-1397	
		Antenna Assembly	Antenna assy - 850	1200-9463	
			Antenna assy - 900	1201-8563	
		Battery Cover	Battery Cover - Black	1205-4137	
			Battery Cover - Dark Grey	1202-0683	
			Battery Cover – Purple	1200-7793	
			Battery Cover – Silver	1214-0287	











Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Coax Cable Gasket	Coax Cable Gasket	1201-1484	
		Cobrand Inlay Assembly	Cobrand Inlay Assy	1201-0785	
			Cobrand Inlay assy, Walkman - Black	1202-0672	
			Cobrand Inlay assy, CMCC - Silver	1206-7053	
			Cobrand Inlay assy, Orange - Black	1206-7039	
			Cobrand Inlay assy, Orange - Silver	1206-7033	
			Cobrand Inlay assy, Telefonica - Black	1206-7047	
			Cobrand Inlay assy, Telefonica - Silver	1206-7043	
			Cobrand Inlay assy, TIM - Black	1206-7058	
			Cobrand Inlay assy, TIM - Silver	1206-7057	
			Cobrand Inlay assy, FIDO - Silver	1208-2937	
			Cobrand Inlay assy, Pink	1214-0261	
			Cobrand Inlay assy, TIM IT Pink	1219-2241	







Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Cover Light Panel	Cover Light panel Assy - Black	1202-0680	
			Cover Light panel Assy - Silver	1201-1916	
			Cover Light panel Assy - Pink	1214-0250	
		Ear Speaker	Ear Speaker	1201-3599	
		ESD gasket	ESD gasket	1206-6016	
		ESD cushion	ESD hinge flex gasket	1206-6021	
		Flex Plug	Flex plug - Black	1205-3427	
			Flex plug - Dark Grey	1202-0488	
			Flex plug - Purple	1200-7760	
			Flex plug - Silver	1214-0171	











Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Hinge	Hinge	1200-9865	
		Hinge FPC	Hinge FPC	1200-6761	
		Hinge Plug	Hinge plug - Black	1205-3195	
			Hinge plug - Dark Grey	1202-0479	
			Hinge plug - Purple	1201-5672	
			Hinge plug - Silver	1214-0172	
		Key Locking Assembly	Key Locking Assembly - Champagne	1205-9618	
			Key Locking Assy - Orange	1205-9617	
			Key Locking Assembly - Turquoise	1205-9615	
			Key Locking Assy - Pink	1205-9614	
		Key Locking Assembly Cover	Key Lock Protective plate	1207-3077	









Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Keyboard	Keyboard Arabic - Silver	1204-3633	
			Keyboard Arabic - Black	1204-5026	
			Keyboard Bopomofo - Silver	1204-3655	
			Keyboard Bopomofo - Black	1204-5029	
			Keyboard Chinese Stroke - Silver	1204-4621	
			Keyboard Chinese Stroke CMCC - Black	1206-4541	
			Keyboard Chinese Stroke CMCC - Silver	1206-4318	
			Keyboard Chinese Stroke - Black	1204-5028	
			Keyboard Cyrillic - Silver	1204-3654	
			Keyboard Cyrillic - Black	1204-5027	
			Keyboard Hebrew - Black	1205-6776	
			Keyboard Hebrew - Silver	1205-6771	
			Keyboard Hindi - Silver	1205-6783	
			Keyboard Hindi - Black	1205-6779	
			Keyboard Latin - Black	1202-0882	
			Keyboard Latin - Silver	1200-7788	
			Keyboard Latin Orange - Black	1204-5035	
			Keyboard Latin Orange - Silver	1204-5034	
			Keyboard Latin TIM - Black	1206-4562	
			Keyboard Latin TIM - Silver	1206-4550	
			Keyboard Thai - Silver	1205-6784	
			Keyboard Thai - Black	1205-6781	
			Keyboard Latin - Pink	1214-0293	Blushing silver
			Keyboard Arabic - Pink	1214-0299	Blushing silver







Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
 		Keyboard (Cont)	Keyboard Bopomofo - Pink	1214-0315	Blushing silver
			Keyboard Chinese - Pink	1214-0318	Blushing silver
			Keyboard Cyrillic Pink	1214-0307	Blushing silver
 		Keyboard FPC Assembly	Keyboard FPC Assy	1201-0039	
 		Keyboard Rubber Base	Keyboard Rubber Base – Pink Center Select	1201-4706	
			Keyboard Rubber Base – Blue Center Select	1202-0897	
			Keyboard Rubber Base – Orange Center Select	1204-3441	
			Keyboard Rubber Base – Champagne Center Select	1204-3443	
			Keyboard Rubber Base – Pearly Pink	1216-0106	Blushing Silver
 		Core Unit Label	Core Unit Label	1200-7792	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Touch Key Assembly	Touch Keys Light Guide/Flex Assy	1206-9506	
		Liquid Intrusion Indicator	Liquid Intrusion Indicator	SXA1094884	
		Loudspeaker	Loudspeaker	1200-9563	
		Lower Front Cover Assembly	Lower front cover assy – Black	1205-3253	
		Lower Back Cover Assembly	Lower Back Cover Assy – Black	1205-3129	
			Lower Back Cover Assy – Dark Grey	1202-0657	
			Lower Back Cover Assy – Purple	1200-7775	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
			Lower Back Cover Assy – Silver	1214-0177	
			Lower front cover assy – Dark Grey	1202-0466	
			Lower front cover assy – Purple	1200-7763	
			Lower front cover assy – Silver	1214-0169	
		Coax cable Conductive Cushion	Coax cable Conductive Cushion	1220-8868	Only the one marked with arrow should be replaced
		Main Window Label	Main window Label – Black	1202-0861	
			Main window Label – Silver	1200-7790	
			Main window Label – Pink	1214-0268	
		Outer Display	Outer Display	1200-7550	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		5IP screw	Screw – 5IP – 1.6X4	1200-9961	
		Philips Screw	Screw – Philips 00 - 1.4X2.5	1201-7762	
		Screw Cover	Screw Cover – Black	1205-4140	
			Screw Cover – Purple	1201-2564	
			Screw Cover – Dark Grey	1202-0686	
			Screw Cover – Silver	1214-0271	
		SIM/M2 Flex	SIM/M2 Flex	1200-6773	
		Outer Display Adhesive	Sub Display Adhesive	1200-9964	

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		System Connector Gasket	System Connector Gasket	1202-7371	
		Upper Back Cover Assembly	Upper Back Cover Assy – Black w/ Champagne logo	1205-3114	
			Upper Back Cover Assy – Black w/ Orange logo	1205-3094	
			Upper Back Cover Assy – Grey w/ Blue logo	1202-0454	
			Upper Back Cover Assy – Purple	1200-7780	
			Upper Back Cover Assy – Silver	1214-0183	
		Upper PBA	Upper PBA	1200-6777	
		Vibrator	Vibrator	1213-5426	New part number

Part	Part Location on Phone	Working Instr. Description	Webshop Description	Part Number	Comments
		Vibrator Clip	Vibrator Clip	1201-8051	
		Camera	Camera – 1.3 Mpixel	1200-8192	
		Volume Key	Volume Key – Black	1204-3461	
			Volume Key – Grey	1202-0852	
			Volume Key – Pink	1200-7787	

3 Revision History

Rev.	Date	Changes / Comments																																								
1	Feb. 29, 2008	Initial Release																																								
2	May 21, 2008	Added 1205-9615 – Key Locking Assembly – Turquoise																																								
3	June 24, 2008	<div>Added:<table><tr><td>Cobrand Inlay assy, Walkman – Black</td><td>1202-0672</td></tr><tr><td>Coax cable Conductive Cushion</td><td>1202-7923</td></tr><tr><td>Protective Plate Tape</td><td>1210-1397</td></tr><tr><td>Key Lock Protective plate</td><td>1207-3077</td></tr><tr><td>Lower front cover assy – Silver</td><td>1214-0169</td></tr><tr><td>Flex plug – Silver</td><td>1214-0171</td></tr><tr><td>Hinge plug – Silver</td><td>1214-0172</td></tr><tr><td>Lower back Cover Assy – Silver</td><td>1214-0177</td></tr><tr><td>Upper Back Cover Assy – Silver</td><td>1214-0183</td></tr><tr><td>Cover – Upper Front Assy – Silver</td><td>1215-5957</td></tr><tr><td>Cobrand Inlay assy, Pink</td><td>1214-0261</td></tr><tr><td>Keyboard Latin Blushing Silver</td><td>1214-0293</td></tr><tr><td>Keyboard Arabic Blushing Silver</td><td>1214-0299</td></tr><tr><td>Keyboard Bopomofo Blushing Silver</td><td>1214-0315</td></tr><tr><td>Keyboard Chinese Blushing silver</td><td>1214-0318</td></tr><tr><td>Main window Label – Pink</td><td>1214-0268</td></tr><tr><td>Cover Light Panel Assy – Pink</td><td>1214-0250</td></tr><tr><td>Screw Cover Assy – Silver</td><td>1214-0271</td></tr><tr><td>Battery Cover – Silver</td><td>1214-0287</td></tr><tr><td>Cobrand Inlay assy, FIDO – Sliver</td><td>1208-2937</td></tr></table></div>	Cobrand Inlay assy, Walkman – Black	1202-0672	Coax cable Conductive Cushion	1202-7923	Protective Plate Tape	1210-1397	Key Lock Protective plate	1207-3077	Lower front cover assy – Silver	1214-0169	Flex plug – Silver	1214-0171	Hinge plug – Silver	1214-0172	Lower back Cover Assy – Silver	1214-0177	Upper Back Cover Assy – Silver	1214-0183	Cover – Upper Front Assy – Silver	1215-5957	Cobrand Inlay assy, Pink	1214-0261	Keyboard Latin Blushing Silver	1214-0293	Keyboard Arabic Blushing Silver	1214-0299	Keyboard Bopomofo Blushing Silver	1214-0315	Keyboard Chinese Blushing silver	1214-0318	Main window Label – Pink	1214-0268	Cover Light Panel Assy – Pink	1214-0250	Screw Cover Assy – Silver	1214-0271	Battery Cover – Silver	1214-0287	Cobrand Inlay assy, FIDO – Sliver	1208-2937
Cobrand Inlay assy, Walkman – Black	1202-0672																																									
Coax cable Conductive Cushion	1202-7923																																									
Protective Plate Tape	1210-1397																																									
Key Lock Protective plate	1207-3077																																									
Lower front cover assy – Silver	1214-0169																																									
Flex plug – Silver	1214-0171																																									
Hinge plug – Silver	1214-0172																																									
Lower back Cover Assy – Silver	1214-0177																																									
Upper Back Cover Assy – Silver	1214-0183																																									
Cover – Upper Front Assy – Silver	1215-5957																																									
Cobrand Inlay assy, Pink	1214-0261																																									
Keyboard Latin Blushing Silver	1214-0293																																									
Keyboard Arabic Blushing Silver	1214-0299																																									
Keyboard Bopomofo Blushing Silver	1214-0315																																									
Keyboard Chinese Blushing silver	1214-0318																																									
Main window Label – Pink	1214-0268																																									
Cover Light Panel Assy – Pink	1214-0250																																									
Screw Cover Assy – Silver	1214-0271																																									
Battery Cover – Silver	1214-0287																																									
Cobrand Inlay assy, FIDO – Sliver	1208-2937																																									
4	June 30. 2008	<div>Changed the parts descriptions of the following: 1214-0293 – From Keyboard Latin Blushing Silver to Keyboard Latin Pink 1214-0299 – From Keyboard Arabic Blushing Silver to Keyboard Arabic Pink 1214-0315 – From Keyboard Bopomofo Blushing Silver to Keyboard Bopomofo Pink 1214-0318 – From Keyboard Chinese Blushing silver to Keyboard Chinese 1215-5957 - From Cover – Upper Front Assy – Silver to Upper Front Cover Assy – Silver</div>																																								
5	Okt 31. 2008	1202-7923 is replaced with 1220-8868																																								



Rev.	Date	Changes / Comments
6	Jan 26 2009	Keyboard Rubber Base – Pearly Pink 1216-0106 added
7	2009-03-15	Cobrand Inlay assy, TIM IT Pink added 1219-2241
8	2009-04-29	Keyboard Cyrillic added 1214-0307
9	2009-05-19	New partnumber on Vibrator changed from 1200-8802 to 1213-5426
10	2009-08-11	New partnumber on “Coax cable Conductive Cushion”, changed from 1202-7923 to 1220-8868