

Part List, Mechanical









Applicable for W760

Contents











1	W760 Parts.....	2
2	Revision History.....	14

Mechanical











1 W760 Parts

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Vibrator	VIBRATOR/ML	BKE90324	
		Camera	Camera (3.2 MPixel)	1201-7111	
		Camera Gasket	Gasket Camera	1201-1051	
		Ear Speaker Housing	Camera Receiver Substrate	1201-1208	











Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Antenna Assembly	Antenna Assembly	1201-1382	
			Antenna Assembly/HW-B	1211-3483	For AT&T and Rogers only
		Side key Flex Assembly	Flex Illumination Assembly	1201-1306	
		Microphone Gasket	Microphone Grommet	1201-1302	
		Ear speaker	RECEIVER/10mm	RLE90731	
		Ear Speaker Gasket	RECEIVER GROMMET	1201-1200	











Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		LCD	Display 2.2 TFT	1209-0361	
		Display Cushion	LCD Cushion Pad	1201-1210	
		LCD Shim	LCD Driver Shim	1210-7829	
		Label	Core unit label	SVF9302621	
		Liquid Intrusion Indicator	Liquid Intrusion Indicator	SXA1094884	









Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Volume Key	Key Volume - Graphite Grey	1204-1075	
			Key Volume - Light Silver	1201-1381	
		Walkman Key	Key Music Walkman	1201-5010	
		Philips Screw - M1.6 (2.1MM in length)	Screw Philips - Len:2.1 Diam:1.6	1208-4895	
		Philips Screw - M1.6 (2.6MM in length)	Screw-Len:2,6 Diam:1.6	1202-3652	
		Philips Screw - M1.6 (3MM in length)	Screw-Len:3, Diam:1.6	1201-1221	







Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		SIM Label	Label, SIM	1202-1861	
		RF Plug	RF Test Plug	1206-9102	
		NeoBon Flex	NeoBon Flex Complete	1201-1204	
		Poron Pad	Poron cushion - 2.36MMX8.5MMX5MM	1210-7840	
		Speaker Box	Speaker Box - Graphite Grey	1204-5842	

Mechanical







Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			Speaker Box - Light Silver	1201-1220	
		Speaker Box Pad	Speaker Box Pad	1210-5696	
		Hinge Assembly	Hinge Assembly	1207-4531	
		A/B Button	Key A/B button - Red	1204-1408	
			Key A/B Button Black	1201-1135	
			Key A/B button Silver	1204-1072	
		Keypad FPC	Main Keypad Flex Complete	1201-1281	

Mechanical





Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Coax Ground	Conductive Coax Ground	1202-3679	
		Rear Frame	Rear Frame - Graphite Grey	1204-1074	
			Rear Frame Light Silver	1201-1290	
		Navigation Keypad	Keyboard Navigation Black	1201-1134	
			Keyboard Navigation Silver	1204-1401	
			Keyboard Navigation Red	1204-1413	
			Keyboard Navigation/ AT&T/Intense Black	1206-8805	
			Keyboard Navigation/ AT&T/Rocky Silver	1206-8806	
			Keyboard Navigation/ AT&T/Red	1207-4302	
			Keyboard Navigation/ Telstra/Rocky Silver	1210-0839	
			Keyboard Navigation/ Telstra/Intense Black	1211-2234	
			Keyboard Navigation/ Telstra/Fancy Red	1211-2238	

Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
------	------------------------	---------------------------------	---------------------	-------------	----------







		Battery Cover	Battery Door Assembly Black	1201-1128	
			Battery Door Assembly Silver	1205-6247	
			Battery Door Assembly Red	1205-6248	
			Battery Door Assembly/ AT&T/Shaded Black	1210-2796	
			Battery Door Assembly/ AT&T/Fancy Red	1210-2803	
			Battery Door Assy TIM IT(Italy) MTV	1211-6129	
			Battery Door Assembly/ AT&T/Rocky Silver	1212-3541	
		Chin Cover	Chin Cover Assembly - Graphite Grey	1205-6201	
			Chin Cover Assembly - Light Silver	1201-9009	
		M2 Cover	Cover M2 Graphite Grey	1204-1395	

Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			Cover M2 Light Silver	1201-1117	
 		Front Frame	Front Frame Complete - Graphite Grey	1205-6232	
			Front Frame Complete - Light Silver	1201-1196	
 		Keyboard	Keyboard Numeric Light Silver	1201-1127	
			Keyboard Numeric Graphite Grey	1204-1402	
			Keyboard Hebrew Graphite Grey	1206-8787	
			Keyboard Cyrillic Graphite Grey	1206-8789	
			Keyboard Arabic Graphite Grey	1206-8790	
			Keyboard Thai Graphite Grey	1206-8792	
			Keyboard Chinese Graphite Grey	1206-8793	
			Keyboard Bopomofo Graphite Grey	1206-8794	
			Keyboard Greek Graphite Grey	1206-8796	
			Keyboard Greek Light Silver	1206-8798	
			Keyboard Hebrew Light Silver	1206-8799	

Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			Keyboard Bopomofo Light Silver	1206-8800	
			Keyboard Cyrillic Light Silver	1206-8801	
			Keyboard Chinese Light Silver	1206-8802	
			Keyboard Arabic Light Silver	1206-8803	
			Keyboard Thai Light Silver	1206-8804	

 	Camera Cover	Top Rear Metal Reflector Mint Green	1204-1419	
		Top Rear Metal Reflector Yellow	1201-1089	
		Top Rear Metal Reflector-Black	1204-1406	
 	Upper Back Cover	Rear Cover Assembly Red	1205-6242	
		Rear Cover Assembly Silver	1205-6238	
		Rear Cover Assembly Black	1201-1046	
		Rear Cover Assy TIM IT (Italy) MTV	1211-6128	
 	Front Cover	Front Cover Assy/Black	1201-1139	
		Front Cover Assy/Red	1205-2542	
		Front Cover Assy/Silver	1205-2544	
		Front Cover Assy/Rogers/Intense Black	1207-9533	
		Front Cover Assy/T-Mobile-	1207-9538	

Mechanical



Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			Intl/ Intense Black		
			Front Cover Assembly /Orange Israel/Rocky Silver	1207-9932	
			Front Cover Assy - CMCC Silver	1207-9933	
			Front Cover Assy/Rogers/ Rocky Silver	1207-9934	
			Front Cover Assy/TMobile-Intl/ Rocky Silver	1207-9937	
			Front Cover Assembly/ Orange Israel/Fancy Red	1207-9959	
			Front Cover Assy/CMCC/ Fancy Red	1207-9961	
			Front Cover Assy/Rogers/ Fancy Red	1207-9962	
			Front Cover Assy/TMobile-Intl/ Fancy Red	1207-9964	
			Front Cover Assembly/AT&T/Black	1208-6999	
			Front Cover Assembly/AT&T/Fancy Red	1208-7439	
			Front Cover Assy/Hutchison/ Intense Black	1209-7162	
			Front Cover Assy/Hutchison/ Fancy Red	1209-7175	
			Front Cover Assy/Hutchison/ Rocky Silver	1209-7188	
			Front cover assy TIM IT (Italy) Intense Black	1210-0181	
			Front cover assy TIM IT (Italy) Rocky Silver	1210-0182	
			Front Cover assy TIM IT	1210-0183	



Mechanical

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			(Italy) Fancy Red		
			Front Cover Assy/Telstra/Rocky Silver	1210-0863	
			Front Cover Assy TIM IT(Italy) MTV	1211-6102	
			Front Cover Assembly/ AT&T/Rocky Silver	1211-8455	
			Front Cover Assy/ Telstra/Intense Black	1212-5078	
			Front Cover Assembly/ Telstra/Fancy Red	1212-5082	

Mechanical

		NeoBon Flex Adhesives	1225-0516	M2 area adhesive	
			1225-0529	PCB area adhesive	
			1225-0532	A/B button adhesive side A	
			1225-0533	A/B button adhesive side B	
			HPM-64 WALKMAN SILVER HPM-64 WALKMAN RED HPM-64 WALKMAN BLACK	1209-3891 1209-3888 1209-3893	



2 Revision History

Rev.	Date	Changes / Comments																					
1	May 29, 2008	Initial Release																					
2	July 10, 2008	<div>Added</div> <table><tr><td>1212-5078</td><td>Front Cover Assembly/Telstra/Intense Black</td></tr><tr><td>1211-2234</td><td>Keyboard Navigation/Telstra/Intense Black</td></tr><tr><td>1210-0839</td><td>Keyboard Navigation/Telstra/Rocky Silver</td></tr><tr><td>1210-0863</td><td>Front Cover Assembly/Telstra/Rocky Silver</td></tr><tr><td>1211-3483</td><td>Antenna Assembly/HW-B</td></tr><tr><td>1208-6999</td><td>Front Cover Assembly/AT&T/Black</td></tr><tr><td>1210-2796</td><td>Battery Door Assembly/AT&T/Shaded Black</td></tr><tr><td>1206-8805</td><td>Keyboard Navigation/AT&T/Intense Black</td></tr></table> <div>Removed</div> <table><tr><td>1207-9532</td><td>Front Cover Assembly/CMCC/ Intense Black</td></tr><tr><td>1210-0185</td><td>Front Cover assembly/SFR/ Rocky Silver</td></tr></table>		1212-5078	Front Cover Assembly/Telstra/Intense Black	1211-2234	Keyboard Navigation/Telstra/Intense Black	1210-0839	Keyboard Navigation/Telstra/Rocky Silver	1210-0863	Front Cover Assembly/Telstra/Rocky Silver	1211-3483	Antenna Assembly/HW-B	1208-6999	Front Cover Assembly/AT&T/Black	1210-2796	Battery Door Assembly/AT&T/Shaded Black	1206-8805	Keyboard Navigation/AT&T/Intense Black	1207-9532	Front Cover Assembly/CMCC/ Intense Black	1210-0185	Front Cover assembly/SFR/ Rocky Silver
1212-5078	Front Cover Assembly/Telstra/Intense Black																						
1211-2234	Keyboard Navigation/Telstra/Intense Black																						
1210-0839	Keyboard Navigation/Telstra/Rocky Silver																						
1210-0863	Front Cover Assembly/Telstra/Rocky Silver																						
1211-3483	Antenna Assembly/HW-B																						
1208-6999	Front Cover Assembly/AT&T/Black																						
1210-2796	Battery Door Assembly/AT&T/Shaded Black																						
1206-8805	Keyboard Navigation/AT&T/Intense Black																						
1207-9532	Front Cover Assembly/CMCC/ Intense Black																						
1210-0185	Front Cover assembly/SFR/ Rocky Silver																						
3	July 22, 2008	Updated part naming based on LVR report																					
4	July 25, 2008	<div>Added</div> <table><tr><td>1210-2803</td><td>Battery Door Assembly/AT&T/Fancy Red</td></tr><tr><td>1212-3541</td><td>Battery Door Assembly/AT&T/Rocky Silver</td></tr><tr><td>1208-7439</td><td>Front Cover Assembly/AT&T/Fancy Red</td></tr><tr><td>1211-8455</td><td>Front Cover Assembly/AT&T/Rocky Silver</td></tr><tr><td>1207-9959</td><td>Front Cover Assembly/Orange Israel/Fancy Red</td></tr><tr><td>1207-9932</td><td>Front Cover Assembly/Orange Israel/Rocky Silver</td></tr><tr><td>1212-5082</td><td>Front Cover Assembly/Telstra/Fancy Red</td></tr><tr><td>1207-4302</td><td>Keyboard Navigation/AT&T/Red</td></tr><tr><td>1206-8806</td><td>Keyboard Navigation/AT&T/Rocky Silver</td></tr><tr><td>1211-2238</td><td>Keyboard Navigation/Telstra/Fancy Red</td></tr></table>		1210-2803	Battery Door Assembly/AT&T/Fancy Red	1212-3541	Battery Door Assembly/AT&T/Rocky Silver	1208-7439	Front Cover Assembly/AT&T/Fancy Red	1211-8455	Front Cover Assembly/AT&T/Rocky Silver	1207-9959	Front Cover Assembly/Orange Israel/Fancy Red	1207-9932	Front Cover Assembly/Orange Israel/Rocky Silver	1212-5082	Front Cover Assembly/Telstra/Fancy Red	1207-4302	Keyboard Navigation/AT&T/Red	1206-8806	Keyboard Navigation/AT&T/Rocky Silver	1211-2238	Keyboard Navigation/Telstra/Fancy Red
1210-2803	Battery Door Assembly/AT&T/Fancy Red																						
1212-3541	Battery Door Assembly/AT&T/Rocky Silver																						
1208-7439	Front Cover Assembly/AT&T/Fancy Red																						
1211-8455	Front Cover Assembly/AT&T/Rocky Silver																						
1207-9959	Front Cover Assembly/Orange Israel/Fancy Red																						
1207-9932	Front Cover Assembly/Orange Israel/Rocky Silver																						
1212-5082	Front Cover Assembly/Telstra/Fancy Red																						
1207-4302	Keyboard Navigation/AT&T/Red																						
1206-8806	Keyboard Navigation/AT&T/Rocky Silver																						
1211-2238	Keyboard Navigation/Telstra/Fancy Red																						



Mechanical

Rev.	Date	Changes / Comments
5	Sept. 15, 2008	Changed the display 2.2 TFT part number from 1201-1093 to 1209-0361
6	2009-03-02	No update
7	2009-03-02	Added parts, NeoBon Flex Adhesives
8	2009-08-27	Added HPM-64 WALKMAN Silver, Red, Black